




# **Ion612**

## **Desiccant Dehumidifier**



## **User's Manual**

Inside you will find many helpful hints on how to use and maintain your dehumidifier properly. Just a little preventative care can save you money and prolong the life of your unit.

INDEX

IMPORTANT SAFETY INSTRUCTIONS ..... 1

FEATURES ..... 2

SPECIFICATIONS ..... 3

PRODUCT DESCRIPTION ..... 3

THE CONTROL PANEL ..... 4

UNIT SETUP..... 5

TO OPERATE SAFELY ..... 5

OPERATING INSTRUCTIONS ..... 6-8

TO EMPTY THE BUCKET ..... 9

TO DRAIN WATER (Continuous Drainage) ..... 9

MAINTENANCE ..... 10

TROUBLESHOOTING .....11-12

WARRANTY DETAILS ..... 13

# IMPORTANT SAFETY INSTRUCTIONS

## PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE OPERATING.

**WARNING** - This appliance is intended for use in a domestic environment and light office use only. Any other use is not recommended by the manufacturer and may cause fire, electrical shocks or other injury to person or property.

When using electrical appliances, basic safety precautions should always be followed:

1. Do not operate the unit with a damaged cord or plug, after it malfunctions or has been dropped or damaged in any way. Return to an authorized service facility for examination and repair.
2. This unit should always be kept in an upright position to avoid any damage. The appliance must be placed on a level flat surface during operation.
3. Check the household voltage to ensure it matches the units rated specification before operating.
4. Operate this unit in an ambient temperature between 1°C and 40°C.
5. Ensure that the air inlets and outlets are not blocked or covered.
6. Do not place the unit too close to curtains or other objects - min 40cm.
7. When using the "LAUNDRY MODE" to speed up the drying of wet clothes in the room, please keep the clothing at a safe distance from the unit to prevent water from dropping onto the unit.
8. Never place anything on top of the unit and do not cover with any kind of material while in use.
9. This product is intended for domestic and light office use ONLY and not for commercial, industrial or outdoor use.
10. To protect against electrical shocks, do not immerse unit, plug or cord in water, or spray with liquids.
11. Never unplug the power cord without press the "ON/OFF" key to off first, as this could damage the unit.
12. Always unplug the unit when not in use or moving location. To disconnect from the power supply, grip the plug and pull from the power socket. Never pull by the cord.
13. Always empty the water tank before storing the unit away.
14. Close supervision is necessary when any appliance is used by or near children and pets.
15. Do not run power cord under carpeting, or cover with rugs or runners. Arrange the cord away from areas where it may be tripped over.
16. Never operate or store the unit in direct sunlight.
17. To repair the unit, take it to a qualified service engineer. Repairs carried out by unqualified people may cause damage to the unit or injury to persons or property and void the warranty.
18. Where possible, avoid the use of an extension cable as they may overheat and cause a risk of fire. Only use an extension cord after ensuring it is in perfect condition.
19. Do not use the unit without the air filter.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

**SAVE AND READ THESE IMPORTANT SAFETY INSTRUCTIONS**

## FEATURES

- **Compressorless dehumidifier** - uses desiccant rotor technology
- **Moisture removal** - 7 litres/day (20°C RH60%)
- **Water tank capacity** - 2 litres
- **Silver Nano technology filter**  
Kills bacteria on contact, improving the quality of air in your home or office
- **Built-in ioniser**
- **Electronic louvre**
- **Laundry mode** - helps to dry out damp clothes
- **Up to 8 hour timer** - for added convenience
- **Temperature range for use** ~ 1°C - 40°C
- **Light & portable with carry handle**
- **Removable water bucket with handle**
- **Operating light**
- **Auto restart after power cut**  
Once the power is restored after a power failure, the appliance will continue to operate at the selected settings prior to the power failure.

## SPECIFICATIONS

Model: Ionmax Ion612


Water tank capacity: 2 Litres

Power Consumption: 360W- 620W


Voltage: 220-240V ~ 50Hz

Net Weight: 6 Kg


## PRODUCT DESCRIPTION



# THE CONTROL PANEL



# OPERATING INSTRUCTIONS



## ON and OFF

Connect the power plug to the appropriate electrical socket outlet.

Press the ON/OFF button to turn the appliance ON.

Press the ON/OFF button again to turn the appliance OFF.

### **Note: In the event of a power failure**

Once the power is restored after a power failure, the appliance will continue to operate at the selected settings prior to the power failure.

This includes the drying mode, swing function and time remaining in timer mode.

### **Note: After turning the appliance OFF**

After turning the appliance OFF using the ON/OFF button, the fan will continue to run for a two minute period. This is a normal procedure and helps to cool & protect the internal components. During this two minutes DO NOT remove the power plug from the electrical socket outlet; wait for the fan to stop running.

# OPERATING INSTRUCTIONS

## AUTO DRY

- Press the "AUTO DRY" Key for automatic dehumidification.

MODE	DESCRIPTION
<b>Auto</b> 55~60%RH	<b>To keep the room at a comfortable Relative Humidity (RH) level</b> <ul style="list-style-type: none"><li>● The unit automatically keeps room humidity 55~60% RH.</li><li>● The fan speed &amp; heater power are adjusted automatically.</li></ul>
<b>Low (Quiet)</b> 55~60%RH	<b>To run low fan speed</b> <ul style="list-style-type: none"><li>● The unit automatically dehumidifies in low fan speed and low noise.</li></ul>
<b>High</b> 40~45%RH	<b>Super dry mode to prevent condensation</b> <ul style="list-style-type: none"><li>● The unit automatically keeps room humidity at 40~45% RH to prevent condensation in the room.</li></ul>

## LAUNDRY MODE

- Press the "LAUNDRY MODE" key for drying clothes or continuous running.



MODE	DESCRIPTION
<b>Saving</b>	<b>Suitable for summer to save power</b> <ul style="list-style-type: none"><li>● The unit automatically provides warm dry air to assist in clothes drying with low power.</li></ul>
<b>Turbo</b>	<b>Suitable in winter to dry clothes faster</b> <ul style="list-style-type: none"><li>● The unit automatically provides heated air to dry clothes faster with higher power.</li></ul>

## ION

- Press the "ION" Key to turn on and off the ioniser. When the LED is on the unit release negative negative ions from the air outlet to purify the air.

Tip: Whilst the dehumidifier is running on fan mode only, turning on the ioniser effectively purifies the air with negative ions and silver ion filtration.




Negative ions has a normalising effect on our bodies, providing the ideal conditions for the body to function better, helps breathing and relaxation.





# OPERATING INSTRUCTIONS

## AUTO SWING LOUVRE

- Press the "SWING" Key to select air louvre angle.

MODE	DESCRIPTION
Up	<ul style="list-style-type: none"><li>• The automatic louvre swings in an upward range of approx 100°</li></ul> 
Front	<ul style="list-style-type: none"><li>• The automatic louvre swings in a front range of approx 50°</li></ul> 
Wide	<ul style="list-style-type: none"><li>• The automatic louvre swing in a wide range of approx 150°</li></ul> 
Hold	<ul style="list-style-type: none"><li>• The automatic louvre stops swinging when you press "SWING" key and turns the LED off.</li></ul>

## 3D Louvre Adjustment

<b>Wide airflow</b> --- rotate to the WIDE position	
<b>Spot airflow</b> --- rotate to the SPOT position	


Note: Do not touch the louvre with your hands while it is swinging. The range of swing will change.

## TIMER MODE

- Press the "TIMER" Key to select your desired running time (2,4 or 8 hours).  
The unit will automatically switch off at the end of the selected time period.  
As the time counts down the LED (4 or 2 hours) lights will indicate the time remaining.
- When no "TIMER" is set (the LED is off), the unit will run continuously, unless the bucket is already full.

## TO EMPTY THE BUCKET

1. When the bucket is full, the "FULL" LED lights and the unit stops in a few minutes
2. Do not move the unit or remove the bucket, if the machine is still operating, as water may leak, damage the unit or cause an electric shock.
3. To remove the bucket, pull it out gently by gripping the bottom of the bucket, and lift carefully.
4. Remove the cover of bucket first, then pour the water away, clean the bucket and restore the cover and the bucket to the correct position.



### NOTE :

- Clean the bucket with clean water if needed. Do not use detergent, solvent, abrasive or hot water to avoid damage to the appliance.
- Do not remove or damage the float in the bucket, or the unit cannot work correctly.
- The bucket cover must be well fitted in position.
- The "FULL" Led lights if the bucket is not well in place.


## TO DRAIN WATER (Continuous Drainage)

You may use a hose with an inner diameter of 12mm for continuous drainage:

1. Use a screwdriver to remove the knockout at the back. Attach the hose to the connector through the hole.
2. The hose must lead to an appropriate drain at a downward slope with no sharp bends.


### Note:

1. Ensure the bucket is well fitted in position before inserting the hose.
2. Before removing the bucket, ensure that the hose is disconnected.



## Cleaning the unit

1. Turn off the unit, wait for the fan to stop and unplug from the power socket.
2. Clean the surface with a soft damp cloth.
3. Dry thoroughly with a towel after cleaning.
4. In order to avoid damage, do not wash the machine with water, or let water drip into the air inlet or outlet.




## Cleaning the filter

If the filter is covered with dust, the airflow and the performance of the unit will be affected. Check the filter periodically to ensure any dust is removed (It is recommended to check and clean the air filter every 2 weeks or an appropriate frequency depending on your usage and air environment).

### How to Clean


1. Turn off the unit and remove the filter from the unit.
2. Clean the nano-silver filter only with a vacuum cleaner.  
(Washing will weaken the germicidal effect of the filter)
3. Replace the filter in position.



## Before storing

1. Turn off the unit, wait for it to stop and unplug from the power socket.
2. Clean and dry the bucket. Leave the unit to drain for approximately one day.
3. Clean the filter and the unit. Cover the unit to prevent it from gathering dust. Store upright in a cool dry place.
4. Do not expose to direct sunlight.

## UNIT SETUP



- Place the unit in an upright position on a stable, flat surface.
- Please ensure the unit is a safe distance away from a wall or furniture (see the right graphic).
- Please keep clothes at a safe distance of 60 cm from air outlet of the unit to prevent water dripping into the unit.
- Where to position your dehumidifier?

For best results position the dehumidifier somewhere central like a landing or a hallway. As long as the internal doors are open the excess moisture from all of the rooms in the house will migrate naturally towards the dehumidifier and be processed.



**CAUTION:** Do not place the dehumidifier in a broom cupboard, boiler room, small unventilated rooms etc. Avoid placing the dehumidifier in small confined areas or in close proximity to a radiator or heat source such as tumble driers, cookers etc. to avoid the dehumidifier from overheating.




Do not use this dehumidifier in dusty or an industrial environment where particles can get into the dehumidifier. This will cause a malfunction and void your warranty.



## TO OPERATE SAFELY

Do not insert small objects into the unit or this will damage it and cause a hazard.



Keep suitable space as above

Do not remove bucket when running or water may leak.

Ensure bucket is fitted correctly, if the bucket is full or is not in place, the "FULL" lights and the machine stops.

# TROUBLESHOOTING

The following conditions are normal:

1. The fan is still running about 2 minutes after turning off the the unit.
2. The unit works within room temperature about 1~40°C. It may stop operation out of this range or when the air inlet or outlet is covered. (The "CHECK" LED light will illuminate)
3. The unit includes heater function that could increase the room temperature.

If your Dehumidifier stops working or "CHECK" LED illuminates, please check the following items first.

## **When the unit fails to run:**

- ➡ Is power cord unplugged or the power off?
- ➡ Is "FULL" light on? Check the bucket is well in position?  
Check and replace the bucket. Ensure unit is on a level and flat surface.

## **When the performance seems poor:**

- ➡ Is there any door or window open?
- ➡ Is steam being generated in the room?
- ➡ Is the room too big?
- ➡ Is the filter dirty? Clean it. Refer to the filter cleaning instructions.
- ➡ Is the inlet or the outlet covered?
- ➡ Try the laundry mode operation and let it run in this mode for a day.
- ➡ Is the unit covered?
- ➡ Is the unit positioned at the required minimum distances away from walls or objects?  
(See page 6 Unit Setup)

## **When noise occurs:**

- ➡ Is the unit on a horizontal flat and level surface? Move and reset the unit.
- ➡ Is the air filter dirty? Clean the filter.

## **NOTE:**

1. If the "CHECK" LED illuminates, turn off the unit, unplug from the power socket, check and clean the filter. If it is dirty, remove any obstacle that covers the air inlet or outlet, and wait for at least ten minutes before plugging in and switching back on.
2. Please contact Andatech at 1300 800 200 if the problem continues.

**Do not try to repair it by yourself, as this could cause an electrical shock and void your warranty.**

## Smell coming from the dehumidifier

When you first use the dehumidifier and periodically afterwards you might notice a smell coming from the dehumidifier. This is caused by the Zeolite desiccant material and is not a sign that the dehumidifier is faulty, nor is it harmful to humans or pets. The smell occurs because the Zeolite absorbs odours from items like cigarettes, cosmetics, hair sprays, building materials and new furniture and then when the desiccant is heated the smell is discharged into the room. This smell has been described as being like a burning smell or a sour smell. It is normal, will not last long and is not a sign of a fault.

## Amount of water collected

When you first use your dehumidifier it will work harder to reduce the room humidity to its target of eg. 55-60%RH (on Auto mode), this is the time when it will produce the most water and need emptying most frequently. As the room becomes dryer the dehumidifier collects less water and runs at a lower fan speed. This is normal. When the target relative humidity has been reached the air coming out of the dehumidifier will not be heated and it will only be running in low fan mode. This is because there is no need for dehumidification at this point and the dehumidifier is sampling the air to check the current relative humidity to see if dehumidification is required.

If you find that you still have condensation on your windows or you need to dry the air further then using the High fan speed, or the Turbo Laundry mode, will force the dehumidifier to dry the air further to 40-45%RH. This might well be necessary if you have single glazed windows or if the outside air temperature drops to freezing.

## Ventilation

The dehumidifier must not be placed in a confined space. Move the dehumidifier to a well ventilated area for example in a hallway, landing or a ventilated room. Ensure that its not in close proximity to any form of heat source, such as a radiator or appliances that generate heat (eg tumble dryer or cooker). The air inlet and outlet must not be obstructed.



## WARRANTY DETAILS

**Congratulations on your purchase!** It is our aim to provide you with quality products that you can trust. Our products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or a refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

### The Guarantee

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from date of purchase for domestic use and 3 months for commercial use. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion, solely at our option with no charge for parts and labour. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Trade Practises Act and similar state laws.

### Proof of Purchase

This warranty is valid for the original purchase and is not transferable. Please keep your purchase docket or receipt as proof of purchase and as proof of date on which the purchase was made. The purchase docket (or a copy) or receipt must be presented with the warranty when making a claim under this warranty.

### Service during the Warranty Period

Please ensure that the RA# (Return Authorization Number) is clearly stated on the outside of the packaging. Don't have one? Call us on 1300 800 200 and we'll get you one. Please ensure the product is properly packaged so as to ensure that no damage occurs to the product during transit.

### Extent of Warranty

This warranty is limited to defects in workmanship or parts. All defective products or parts will be repaired or replaced. This warranty does not cover manuals and packaging.

### Normal Wear and Tear

This warranty does not cover normal wear and tear to the product or parts.

### Exclusions

This warranty does not cover:

- Any defect caused by an accident, misuse, abuse, improper operation, lack of reasonable care, unauthorised modification, loss of parts, tampering or attempted repair by a person not authorised by the distributor.
- Any product that has been damaged by a lightning strike either directly or indirectly or a mains power surge or liquid ingress.
- The product if it is located outside of Australia.
- Any damage caused by improper power input or improper cable connection.

---

### Andatech Corporation Pty. Ltd.

Factory 7, 2-4 Apollo Court, Blackburn Victoria 3130

Phone: 1300 800 200 Fax: 1300 883 802 Email: [info@andatech.com.au](mailto:info@andatech.com.au)

**1**  
YEAR  
WARRANTY

