



Bluetooth

How to reset your BST-400

- 1 Unplug the Charging Cable from your BST-400.
- 2 Locate the Headphone Jack on back of the BST-400.



Headphone Jack

- 3 Insert a paperclip end inside the Headphone Jack to press the Reset Button located at the bottom of the Headphone Jack.

