



Cool & Warm Mist Humidifier with UV ION90

Exquisitely designed with its classy and clean outline, Ionmax hybrid humidifier ION90 with UV is a must-have in every modern home. Packed with features like UV Bio-Photocatalyst sterilisation and deodorisation, Duo-Humidification Technologies and Hygrostat for Pre-set Humidity level, this whisper-quiet beauty promises scintillating functionality that one takes pleasure in.

Low humidity levels can cause or aggravate symptoms of respiratory illnesses e.g. blocked or stuffy and running nose, breathing difficulties, chapped skin, sore and dry throat and eyes, and fatigue. A humidifier like the ION90 reintroduces moisture into the air and can help alleviate symptoms effectively and create a more comfortable and healthy living environment.

Features



Control Mist Output

Regulate the mist volume of your ION90 between Low, Medium or High. The ION90 also has a dual mist outlet which can be rotated accordingly so you can achieve more comprehensive coverage of your surroundings for optimal efficiency.



Large 6.5L tank capacity

With a larger tank capacity, you can enjoy at least 21 hours of continuous cool mist humidification, or 16 hours on warm mist.



Water Shortage Indicator

Notifies you when the water tank is empty so that you can switch off the unit or refill it for continued operation.



Cool and Warm Mist

Produces Heat Vapourising (Warm Mist) for faster humidification and Ultrasonic Humidification (Cool Mist) for mist at room temperature.



Auto Switch Off when Tank is Empty

Safety feature that switches off the humidifier if the tank is empty to prevent a hazard.



Built-In Ioniser

Emits millions of negative ions to help clean and revitalise the air.



UV Bio-Photocatalyst Sterilisation

Environmentally friendly oxidising agent activated by UV ray to decompose smelly particles and achieve maximum deodorisation and sterilisation effects.



Demineralisation Filter

When water goes through the Demineralisation Filter, it is restructured at an ionic level and the dissolved mineral salts and other additives are removed, thereby softening the water. This aids in reducing mineral buildup at the nebuliser and finer ultrasonic humidification.



Room Coverage 16-30 sqm

Suitable for rooms up to 30sqm. Great for the living room, dining area or bedroom.



Quiet Operation

Silent operation making it suitable for use at night while sleeping and in the kids' or baby's bedroom.



Humidistat and Hygrostat

Features a built-in humidistat that tells you the current humidity level and a hydrostat that facilitates in continuously moderating and sustaining your desired humidity level.



Timer Settings

The ION90 can be programmed to run from 1 to 9 hours or continuously.



Adjustable Humidistat

Easily maintain the desired humidity in your home with the inbuilt adjustable humidistat.



Sleep Mode

LCD becomes dimmer with the relative humidity set at 60%. It will operate continuously for 8 hours with WARM on before powering off automatically.

Specifications

Model No.	ION90
Input Voltage	240 V
Power Consumption	Ultrasonic: 40 Watts; Heat Vapouriser: 125Watts
Humidification Rate	Ultrasonic: 300ml/hr; Heat Vapourising: 400ml/hr

Coverage Area	16-30 sqm
Tank Capacity	6.5L
Product Weight	3.5kg
Dimensions	315mm (H) x 180mm (W) x 260mm (D)
Warranty	1 year