

PHILIPS

Air humidifier

Safe & clean

NanoCloud technology

Automatic

Digital sensor



HU4803/70



Healthy air, always

with NanoCloud technology and automatic control

Automatic control and smart evaporation technology. Philips air humidifier fights dry air with precision. It evenly distributes humidified air throughout the room and has 99% less bacterial spreading compared with ultra sonic ones.

Healthy Air

- Evenly distributes humidified air throughout the room
- Automatic humidity mode for your peace of mind
- Humidification settings allow for precise humidity control
- Hygienically safer, no white dust* and no wet desktop

Always

- Healthy air protect alert warns you when to refill the tank
- Auto shut down when humidifier runs out of water

Simplicity

- Choose between silent, standard and auto humidification
- 1/4/8 hours easy-to-set timer
- Easy-fill tank
- Minimalist design gives you best-in-class cleanability
- Sleep mode when the humidifier runs with minimum lights on

Highlights

NanoCloud technology



This Philips air humidifier offers a three-stage advanced evaporation system with NanoCloud technology. Stage 1: the absorbent filter on the humidifier catches big particles such as human/pet hair and dust when drawing in the dry air. Stage 2: the advanced evaporation system with NanoCloud technology humidifies the air by adding water molecules to the air and does not carry bacteria or scale. Stage 3: healthy air gets blown out of the humidifier at a constant speed, delivering comfortable, healthy humid air without formation of water mist in your home.

Comfortable humidification

Evenly distributes humidified air throughout the room. Breathe and sleep better at home with healthy humidified air

Precise humidity settings

The Philips Air humidifier allows you to choose between 40, 50 and 60 percent humidity in the air for maximum comfort.

Automatic humidity mode

The automatic mode uses the digital sensor to constantly monitor the air humidity and will turn on and off your humidifier whenever needed, ensuring the humidity level is constantly at the right level

Healthy air protect alert

Red light alert warns you when to refill the tank

Healthy air protect lock

When the water tank is empty and needs to be refilled, the healthy air protect lock shuts off the humidifier and a red indicator lights up telling you that the humidifier has stopped.

1/4/8 hours easy-to-set timer

Appliance operates for a set number of hours and automatically switches off when set time has elapsed.

Dedicated sleep mode

Dedicated sleep mode when the humidifier runs at minimum noise level and all lights are off except the speed indicator

Triple humidification speed

Choose between silent, standard and auto humidification to allow flexibility.

Best-in-class cleanability

Cleaning humidifiers inside and out – especially the water tank – has never been easier

Easy-to-fill tank

Fill with a jar or bring the water tank to the tap. The 'max' indicator clearly shows how far to fill the tank. When the tank is empty, the humidifier automatically shuts off and the display indicates a re-fill is needed.

Specifications

Design and finishing

Color(s): White and oyster metallic

Air quality sensor(s): Humidity sensor

Technical specifications

Effective area: 25 m²

Sound level: As low as 26db at silent mode dB(A)

Voltage: 220-240 V

Weight and dimensions

Dimensions of product (LxWxH): 249 x 249 x 339 mm

Performance

Humidification rate: 220 ml/h

